



**MARINE
CARE**

AM SCALE REMOVER POWDER

Highly effective scale remover for vacuum toilet systems

- High efficiency
- Easily soluble in water
- Removes scales in vacuum systems
- Non corrosive
- 100% biodegradable

DESCRIPTION

AM Scale Remover powder is a blend of non corrosive organic acid, detergents and surfactants specially developed for the removal of scales in Vacuum toilet systems. AM Scale Remover powder is highly effective on urea stones and similar scales present in lines and headers of vacuum toilet systems.

ADVANTAGE

- Economical to use
- Non corrosive
- Easily soluble in water; dissolves rapidly
- Removes urea scales from Vacuum systems

APPLICATIONS

AM Scale Remover powder is mainly used for cleaning of Vacuum toilet systems.

SCALE PREVENTION

For daily dosages to prevent scales in vacuum toilet system AM Scale Remover *Liquid* is to be used.



Revision	0.0	Document number	PDS-08-208
Date of issue	02-07-2019	Page	1 of 2

MARINE CARE BV
Oude Maasweg 35
Port number 4005
3197 KJ Rotterdam Botlek
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. operations@marinecare.nl
W. www.marinecare.nl



MARINE CARE

DIRECTIONS FOR USE

Prepare the section of the vacuum system to be cleaned. Ensure it is possible to circulate, no blockages are present and prevent dead legs. Dissolve 5-10% AM Scale Remover Powder in warm water. Flush the solution through the system for 1-2 hours. In case of heavy scale build up (> 5 mm) stronger AM Scale Remover Powder is required, but do not dose more than 20% AM Scale Remover Powder. When scale is still present reclean the system with a fresh solution of AM Scale Remover Powder.

PROPERTIES

Flashpoint	> 100 °C
Physical state	powder

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.

AM SCALE REMOVER POWDER

- High efficiency
- Easily soluble in water
- Removes scales in vacuum systems
- Non corrosive
- 100% biodegradable



MARINE CARE BV
Oude Maasweg 35
Port number 4005
3197 KJ Rotterdam Botlek
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. operations@marinecare.nl
W. www.marinecare.nl

Revision	0.0	Document number	PDS-08-207
Date of issue	02-07-2019	Page	2 of 2

This information is based on data that we believe to be accurate and reliable and is intended to be used by persons having the knowledge and skill to apply this product properly. We assume no responsibility for results or damages incurred from their use by the Buyer. No liability (including liability for negligence) will attach to Marine Care or its servants or agents arising out of or in connection with or in relation to this product information.